



Counterfeit Detector Pen

Instruction Booklet

IMPORTANT:

READ INSTRUCTIONS PRIOR TO USE

Visit our website
www.DriMark.com

The Original Counterfeit Pen

IMPORTANT:

Replace the cap on the detector pen immediately after use. False readings can result if the pen tip is left exposed for more than a minute or two. This product is highly effective if used correctly, but is not guaranteed to detect 100% of counterfeit tones. Visit www.DriMark.com for more information and other fine products for counterfeit detection.

MANUFACTURERS LIMITED WARRANTY:


FOR A PERIOD OF 90 DAYS FROM PURCHASE, THIS PRODUCT WILL BE REPLACED, OR THE PURCHASE PRICE REFUNDED IF DEFECTIVE IN MANUFACTURE. EXCEPT FOR SUCH REPLACEMENT OR REFUND, THE SALE OF THIS PRODUCT IS WITHOUT OTHER EXPRESSED OR IMPLIED WARRANTY OR LIABILITY, INCLUDING, BUT NOT LIMITED TO, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR ANY KIND.

CAUTION: DETECTOR PEN

AVOID SKIN, EYES & CLOTHING CONTACT WITH COUNTERFEIT DETECTOR PEN FLUID


DriMark
PRODUCTS INC.

DriMark
PRODUCTS INC.



PASS

Light or yellow mark



FAIL

Dark Mark

Simple to use. Make a small mark on US currency. A clear/amber mark indicates genuine US currency paper. A dark mark means the bill is probably counterfeit. Since currency paper stock is not available to the public, Dri Mark's special ink authenticates the paper's stock by color.